



x  
neverdark

## Thermobox See-Through Hidden Installation (H-TST)


for fireplaces Automatic, Firetec  
Installation instructions








Model	Thermobox			Fireplace	
	A	B	C	X	Y
	Length of the thermobox	Height of the thermobox	Depth of the thermobox	Burner length	Width of the fireplace
H-TST-800	800	400	350	700	250
H-TST-900	900			800	
H-TST-1100	1100			1000	
H-TST-1300	1300			1200	
H-TST-1600	1600			1500	
H-TST-2200	2200			2000	
H-TST-2700	2700			2500	


Thermobox with options












Wall



Wall facing

